
Life Fitness

Classic Upright Bike CLSC-ALLXX-02




Customer Support Services


PARTS MANUAL

rev 15 Feb 2010


Description	Part No.
OPERATION MANUAL	M051-00K63-A263
HARDWARE BAG	GK63-00002-0044
NETWORK C-SAFE KIT	GK63-00002-0003
POWER OPTION KIT – 120V	GK63-00002-0005
POWER OPTION KIT – 220/50 UK	GK63-00002-0039
POWER OPTION KIT – 240V+ AUS	GK63-00002-0040
POWER OPTION KIT – 220/50	GK63-00002-0041
TOUCH UP PAINT: SPRAY CAN .5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	 0017-00008-0204 0017-00008-0205 0017-00008-0206
SERVICE MANUAL	M051-00K63-A009




Language	Console Assembly	Bezel/Switch w/Overlay Assembly
Eng	AK63-00291-0001	AK63-00165-0001
Eng Met	AK63-00291-0002	AK63-00165-0001
Ger Met	AK63-00291-0003	AK63-00165-0003
Spn Met	AK63-00291-0004	AK63-00165-0004
Jap Met	AK63-00291-0006	AK63-00165-0006
Frn Met	AK63-00291-0007	AK63-00165-0007
Itl Met	AK63-00291-0008	AK63-00165-0008
Dut Met	AK63-00291-0009	AK63-00165-0009



Upper Cover
0K63-01145-0001
Lower Cover
0K63-01146-0001
Cover Screws (4)
0017-00101-1744
Console
Mounting Screws (4)
0017-00101-1744
Polar Receiver
AK40-00045-0001
Accessory Tray
0K63-01030-0001
Accessory Tray Screws (4)
0017-00101-1744
Bolts (4)
0017-00101-1755
Washers (4)
0017-00104-0464
(not shown)
Leg leveler
AK61-00035-0000 (2)


Alternator w/Pulley
Ak63-00093-0000






Crank Arm Hub
0K63-01095-0001
Pulley Assembly
AK63-00051-0000
Pulley
0K63-01018-0000
Washers (3)
0017-00104-0458
Flywheel Screws (3)
0017-00101-1715
*Crankshaft & Bearing Kit
GK63-00002-0077
*Crankshaft
0K63-01012-0001
*Small Thrust Washer (2)
0K63-01129-0000
*Large Thrust Washer (2)
0K63-01129-0001
*Bowed Retainer Ring (2)
0017-00100-0243
Washer (2)
0017-00104-0409
*Needle Bearing (2)
0K63-01344-0000
*Small Snap Ring (2)
0017-00100-0241
Crank Arm Hub (2)
0K63-01095-0001
Bolt (2)
0017-00101-1705


Intermediate Shaft and
Bearing Assembly Kit
GK63-00002-0007






Seat Latch Assembly
AK63-00043-0001
Latch Spring
0K63-01117-0000
Latch Bracket
0K63-01064-0000
NYLINER
0017-00042-1129
E-Ring
0017-00100-0050
Setscrews (2)
0017-00101-0333
Latch Rack
0K63-01061-0000
NYLINER
0017-00042-1129
Link Shaft Assembly
AK63-00113-0001



Seat Post Assembly
AK63-00232-0002
Seat Post Decal
0K63-01310-0000
Deluxe Seat Assembly
AK63-00229-0003
Screw
0017-00101-1750
Lock Washers (4)
0017-00104-0064
Hex Bolts (4)
0017-00101-1121
Extrusion Guide Cap
0K63-01044-0000
Seat Post Assembly
AK63-00099-0001
Pan Screws (3)
0017-00101-1614
Spring Support Bracket
0K63-01210-0000
Seat Adjustment Rack
0K63-01049-0001
Guide Base
0K63-01045-0000
Polylastomer Bumper
0017-00042-1131


Left Seat Post Shroud
0K63-01092-0010
Screw
0017-00101-1741
Right Seat Post Shroud
0K63-01092-0009



Idler Bracket Assembly
AK63-00021-0000
Idler Bracket
0K63-01050-0000
Lock Nut
0017-00103-0218
Idler w/Bearing
AK63-00008-0000


End Cap
0K63-01320-0000
Cable Assembly: Jack/Hr
AK36-00021-0003
Console Support
Weldment Assembly
AK63-00089-0002
Polar Bracket
0K63-01113-0000
Support Screws (4)
0017-00101-1755
Washers (4)
0017-00104-0464
(not shown)
Nuts (2)
0017-00103-0318
Pan Screws (4)
0017-00101-1753
HR Electrode Cable
AK63-00069-0000
Handlebar Cover-RT
0K63-01192-0003
Console Cable
AK63-00037-0002
I-Beam Joint
0K63-01178-0002
Handlebar Cover-LT
0K63-01192-0004



Shroud Screws (3)
0017-00101-1741
Left Side Shroud w/decal
AK63-00299-0000
Decal
0K63-01358-0000
Crank Arm Screws (3)
0017-00101-1855
Shroud Plug
0K63-01084-0001
Crank Arm, LT
0K39-01042-0008
Left Pedal
AK63-00263-0004
Left Pedal Strap
0K63-01238-0004



Right Side Shroud w/decal
AK63-00298-0000
Right Pedal
AK63-00263-0003
Right Pedal Strap
0K63-01238-0003
Decal
0K63-01358-0000
Crank Arm Screws (3)
0017-00101-1855
Crank Arm, RT
0K39-01042-0007
Right Side Shroud Screws (8)
0017-00101-1741


PCB Mounting Bracket Assembly
AK63-00049-0000





Front Wheels
AK63-00017-0001




Resistor Assembly
AK63-00047-0001
Resistor
.5 OHM 240 Watt
100E-00002-0092
Nuts (3)
0017-00103-0081
Resistor Mounting Rod
0K63-01166-0000
Retainer
0K63-01215-0000
Pan Screws (2)
0017-00101-1057
Resistor Brackets (2)
0K63-01165-0000
Power Control
Cable Assembly
AK63-00029-0001


Handlebar Assembly
AK63-00091-0001
Molder Grip Handlebar
AK63-00156-0001
Electrode Molded Inserts (4)
AK63-00014-0003
Electrode Cable Assembly
AK63-00028-0001
Insulated Plugs (4)
0K63-01167-0001
Handlebar End Caps (2)
0K63-01114-0001
Phillips Screws (4)
0017-00101-1752


Alternator Belt
0K63-01065-0000
Intermediate Belt
0K63-01066-0001


CABLE ASSEMBLY
POWER CONTROL TO ALTERNATOR
AK63-00029-0001
CONTROL
15 OHMs
Resistor
CONSOLE TO ACB CABLE
AK63-00037-0002
LOWER CONSOLE
CABLE
AK63-00038-0000
CABLE ASSEMBLY
AK63-00028-0001
LIFE PULSE EXTENSION
AK63-00069-0000
P9
UPPER CONSOLE
LOWER CONSOLE
LOWER KEYPAD
UPPER KEYPAD
POLAR CABLE
AK36-00021-0003
POLAR CABLE W/BRACKET
AK63-00120-0000